

T9 Franklin

Mobile Hotspot



User Manual

Charging the Battery

Before using your mobile hotspot, ensure that the battery is fully charged. Be sure to use the charger that came with your device.

- It normally takes 3~5 hours, depending your power sources and device status to fully charge the battery.
- Insert the small end of the USB cable into the micro-USB charging port on the right side of the hotspot.
- Plug the charging adapter into a standard AC power outlet. Battery life depends on the network, signal strength, temperature, features, and active connection time.

Get Ready




- Make sure you are in an area covered by T-Mobile
- Make sure the device you are trying to connect to your Hotspot has its Wi-Fi (wireless network connection mode turned on).

Power up the Hotspot

- To turn your hotspot on or off, press and hold the Power Button on the front of the device for at least two seconds.

Main Screens

Your Hotspot has a series of screen that let you view device information and system alerts. Press the Power Button (Navigation Key) to cycle through the following:



Press  quickly

Home screen, Device menu guide
(Switching every 3 seconds)

Press  quickly

Data usage display

Press  quickly

Wi-Fi Name display

Press  quickly

Password display

Press  quickly

Web Admin URL Guide display

Press  quickly

Back to Home screen

Connecting to Your Hotspot

- Turn on your Hotspot and your Wi-Fi enabled device
- Open the Wi-Fi application or controls on your laptop or Wi-Fi capable device that you want to connect to your Hotspot
- Find your Hotspot's Wi-Fi name and enter your password to connect to the internet. Note: Your Wi-Fi Name (SSID) and Password appear on the Hotspot LCD display.