

USE THE WPS

If your Wi-Fi device supports WPS, you do not have to input the password manually after WPS connection has been established. Please follow the following steps:

1. Power on your Mobile Hotspot and enable the Wi-Fi function.
2. Press and hold the WPS key on your device for 3 seconds to start the Wi-Fi Protected Setup authentication process.
3. Enable the WPS function on your Wi-Fi device in order to respond to this authentication process.
4. Follow the system prompts on your Wi-Fi device to finish the connection.
5. If no Wi-Fi device is connected within 2 minutes, WPS function will automatically close.



Grant R. Brimhall Library - 1401 E. Janss Road, Thousand Oaks, CA 91362 • 805-449-2660
Newbury Park Library - 2331 Borchard Road, Newbury Park, CA 91320 • 805-498-2139

www.tolibrary.org

T-Mobile

Welcome

Start Guide




alcatel
LINKZONE® 2

BC



*inspire
inform
engage*

GETTING TO KNOW YOUR MOBILE HOTSPOT



LED DESCRIPTION

Part	Description
Power key	Hold the Power key for 3 seconds to power the device on/off.
WPS key	Hold the WPS key for 3 seconds to activate the WPS function. Once activated, the Wi-Fi LED indicator will flash every two seconds. If the network is not accessed within 2 minutes, device will automatically exit WPS mode.
LED indicators	Displays Wi-Fi, signal, battery, and SMS status.

Charging in USB Port	Use the USB Type-C port to charge your device and connect your device to the client via the USB cable.
Charging out USB port	Use the USB port to charge other devices, such as tablets and smartphones.
Reset	Press Reset key for 3 seconds to reset device. All LED indicators will flash blue 2 times to indicate that the device has been reset to factory mode.
Reboot	Hold Power key for 10 seconds to restart device.

INDICATORS

When the hotspot is powered on, the following icons will illuminate. For a description of the icons, please refer to the table below:



Wi-Fi Indicator (Blue LED)

Solid Blue

Wi-Fi is active.

Flashing Blue

WPS mode is active.

Signal Indicator (Red or Blue LED)

Solid Blue

Registered and connected to network.

Good coverage: 3 LEDs all light up

Middle coverage: 2 LEDs light up

Weak coverage: 1 LED lights up

Flashing Blue

Network disconnected.

Solid Red

No network, no SIM card or SIM card error, limited or no service.

Battery Indicator (Red or Blue LED)

Solid Blue

3 LEDs light up blue: Battery level 80% - 100%

2 LEDs light up blue: Battery level 40% - 79%

1 LED lights up blue: Battery level 15% - 39%

Solid Red

1 LED lights up red: Battery level 0% - 14%.

Flashing

LEDs will flash while charging. Once the battery level is at 100%, 3 LEDs will display solid blue.

SMS Indicator (Blue LED)

Solid Blue

New message

Slowly Flashing Blue

Message inbox is full.

Off

No new messages.


Software update

Fast Flashing Blue

1. New Software version download or installation is pending.
2. In process of software update installation.

CHARGING YOUR MOBILE HOTSPOT

There are two ways to charge your mobile hotspot:



1. Charge using a charger and USB data cable

Connect the USB cable into the charging port as shown and connect the charger to a power outlet to start charging. When the device is powered off, it takes about 3 hours before being fully charged.

2. Charge using a computer and USB data cable

You can also charge the device by connecting it to a PC with the USB cable.

When the device is powered off, it takes about 4 hours to complete charging.

Note: When red battery indicator lights up, device should be charged in order to protect the battery.

CHARGING OTHER DEVICES

Use the full-size USB port to charge other devices, such as tablets and smartphones.

